



Catalogue de pièces



XRB68




101-1007

XRB68

NO.	PART NO.	PARTNAME	Q'TY
1	00400BH	Back Head	1
2	BHCVBF08	B/H Charging Valve	1
3	00400TBHN	Through Boit Hex. Nul	4
4	00400TBW	Through Boit Washer	4
5	00400TB	Through Boit	4
6	SAS239A	O Ring	3
7	SCG068	Gas Sea!	1
8	SCS068	Step Seal	2
9	00400SR-A	Sea! Retainer	1
10	00400P	Piston	1
11	SBG025	O Ring	1
12	SBG040	O Ring	1
13	00400VC	Valve Cap	1
14	00400V	Valve	1
15	00400VS	Valve Sleeve	1
16	SPBF08	Socket Plug	3
17	SBP018	O Ring	5
18	SABFF08	Screwed Adapter	2
19	ACBF08	Adapter Cap	2
20	ACVBF08-1	Air Check Valve	1
21	00400CY	Cylinder	1
22	SPBT04	Socket Plug	1
23	SCUP070	U-Packing	1
24	SCD070	Oust Sea!	1
25	00400FH-X1	Front Head	1
26	GNBT04	Grease Nipple	1
27	SP1680	Spring Pin	1
28	00400RP	Rod Pin	1
29	00400SP-X1	Stop Pin	2
30	SP1650	Spring Pin	2
31	00400RB-X1	Ring Bush	1
32	00400FC-X1	Front Caver	1
33A	00400T-M	Tool-M Type	1
338	00400T-V	Tool-VType	1
33C	00400T-H	Tool-H Type	1
33D	00400T-C	Tool-C Type	1
33E	00400T-B	Tool-B Type	1
101	00400S	Sea! Kit	1
102	00400V-AY	Valve Assy	1
104	00400TB-AY	Through Boit Assy	4
105	00400TLB-ST	Tool Box Assy	1
106	00400BH-AY	Back Head Assy	1
107	00400CY-AY	Cylinder Assy	1
108	00400FH-X1-AY	Front Head Assy	1

XRB68



101-1008

XRB68

NO.	PART NO.	PARTNAME	Q'TY
1	00400F-B20	Frame	1
2	00400CRD	Cross Damper	1
3	00400BLD	Below Damper	1
4	00400SDA	Side Damper A	7
5	00400SOB	Side Damper B	2
6	00400SDC	Side Damper C	1
7	HBM2085	Hex.Bolt	10
8	W20	Washer	20
9	SW20	Spring Washer	10
10	HNM20	Hex.Nut	20
11	00400CV	Cover Plate	1
12	HBM1030	Hex.Bolt	6
13	W10	Washer	6
14A	00400MC-B	Mount Cap	1
14B	00400MC-B-BH	Mount Cap	1
15	00400MP	Mount Pin	2
16	00400MPR	Mount Pin Ring	2
17	00400MPS	Mount Pin Stopper	2
18	00400MPB	Mount Pin Bush	4
19	HBWH-AY	Hex.Bolt WrthHoleAssy	2